


LOST YOUR LG PROJECTOR REMOTE?



You can purchase your replacement projector remote by following these easy steps:

1. Find your projector model number. (This can be found by looking at the bottom of your projector.)



2. Use the table below to find the remote that corresponds to your projector.

Projector Model	Projector Part Number	Remote Part Number
ProBeam BU70QGA	BU70QGA-GL.AUSLLA	AKB76039802
ProBeam BU60RG	BU60RG-GL.AUSLLA	AKB76039802
ProBeam BU60PST	BU60PST-GL.AUSLLA	AKB75095388
ProBeam BU60PSM	BU60PSM-GL.AUSELA	AKB75095392
ProBeam BU53RG	BU53RG-GL.AUSLLA	AKB76039802
ProBeam BU53PST	BU53PST-GL.AUSLLA	AKB75095392
ProBeam BU50RG	BU50RG-GL.AUSLLA	AKB76039802
ProBeam BU50NST	BU50NST-GL.AUSLLA	AKB75095388
ProBeam BF60RG	BF60RG-GL.AUSLLA	AKB76039802
ProBeam BF60PST	BF60PST-GL.AUSLLA	AKB75095388
ProBeam BF50RG	BF50RG-GL.AUSLLA	AKB76039802
ProBeam BF50NST	BF50NST-GL.AUSLLA	AKB75095388
ProBeam BF40QS	BF40QS-GL.AUSLLA & BF40QS-GL.AUSLMA	AKB75095392
PF510QC	PF510QC-GL.AUSLLAN	AKB76043410
HU85LS	HU85LS-NA.AUSELA & HU85LS-NA.AUSLLA	AKB75735303

3. Go to lgparts.com and in the search bar, enter in your projector remote part number to find your projector's remote.

Scan QR Code to go to lgparts.com

