



# wave™ by LG

## Quick Start Guide



Transferring  
Music



Playing  
Music



Bluetooth®  
Pairing



Sending Contacts  
via Bluetooth®



Taking a Picture/  
Recording a Video

[www.LGUSA.com](http://www.LGUSA.com)

# Getting to Know Your Phone




## Transferring Music

Easily transfer your music (MP3, WMA, AAC, AAC+) as well as your image files between an optional microSD card\* and your PC!

1. Insert a microSD card (gold contacts facing up) into the memory card port on the right side of the phone.
2. The first time you transfer music, you must format the card. Press **OK** and select **Settings (9)**, **Memory (9)**, **External Memory (3)**, then press the **Right Soft Key** for **Format** and press **OK**.
3. With the phone powered up and in standby mode, connect the phone to the PC using a USB cable.\*
4. Press **OK**, select **Settings (9)**, **PC Connection (7)**, then **USB Mass Storage (2)** to establish a connection to the PC.
5. The PC will recognize the phone as a **Removable Disk** under **My Computer**. Transfer your music files by dragging and dropping them into the **LG\_MEDIA > MUSIC** folder.
6. When done, disconnect the cable.

\*Sold separately.

**Warning!** Do not disconnect phone while file transfer is in progress.



# Playing Music



## Playing Music with the Flip Open

1. Insert a microSD card\* with music (gold contacts facing up).
2. Press **left** on the Navigation Key, choose a category, then press **OK** to play.
3. Press **OK** to play/pause the music. Press **right** or **left twice** on the Navigation Key to go to the next or previous song.
4. Press **END** to exit the music player.

## Playing Music with the Flip Closed

1. Insert a microSD card\* with music.
2. With the flip closed, press and *hold* the **Music Key** to unlock the touch keys.
3. Tap **▶▶** or **◀◀** to go to the next or previous song on the list.
4. Tap **▶** to play/pause the music.
5. To exit the music player, tap and *hold* **▶▶** (unlock the touch keys if they're not activated).

\* Sold separately.



## Bluetooth® Pairing

Say goodbye to cord hassles with Bluetooth connectivity to a headset, portable stereo speakers, or laptop. Great for hands-free talk, music, or exchanging contacts.

1. Set your Bluetooth accessory to pairing mode.\*
2. Press **OK**, then select **Settings (9)**.
3. Select **Bluetooth (6)**, then **Paired Devices (1)**.
4. Press the **Left Soft Key** to search. If Bluetooth is set to off, you will be prompted to turn power on. Select **Yes (1)**, then **New Search (1)**.
5. The phone will now search for the accessory. Once found, highlight it and press **OK** to pair.
6. Enter the passcode (typically "0000" - 4 zeroes) and press **OK**.\*
7. Press **OK** to connect with the device.

\* Refer to the user manual of your Bluetooth accessory to activate pairing mode and for the passcode.


**Note:** Bluetooth accessories sold separately.



## Sending Contacts via Bluetooth®





Sharing contact information is made easy. Send a vCard (electronic name card) to easily exchange names and numbers with another vCard-supported mobile phone or device via Bluetooth technology.

1. Press **OK**, select **Settings (9)**.
2. Select **Bluetooth (6)**, then **Paired Devices (1)**.
3. Select the device you want, press the **Right Soft Key** for **Options**, then select **Send vCard (6)**.
4. If Bluetooth is off, press **OK** to turn it on.
5. Press **OK** to select the contact(s) you want to send.
6. When finished, press the **Left Soft Key** to send.





## Taking a Picture/Recording a Video

Snap rich 1.3 megapixel photos or record video clips so you can savor your favorite moments the instant they happen. Share the best ones immediately with friends.

1. To activate camera mode, press the  **Key**. To activate video mode, press and *hold* the  **Key**.
2. Press **left** or **right** on the Navigation Key to adjust brightness and **up** or **down** for zoom.\* Press the **Right Soft Key** to adjust other camera/video options.
3. Press  to take the picture or start/stop recording.
4. Press  for **Yes (1)** to upload the picture/video to your online album. Select **No (2)** to save or send the picture/video.

\* Camera setting of 1280 x 960 does not support zoom function.

**Note:** To take self-portraits with the flip closed, press and *hold* the side  **Key**, then press either volume key to activate the viewfinder. Press  to take the picture.





*wave*<sup>™</sup> by LG

©2007 LG Electronics, Inc. All rights reserved. All other trademarks are property of their respective owners. All phone images are simulated.

WAVEQSG/ALLTEL