



Quick Start Guide

Use your phone for more than just talking

Music Player with 3D Stereo Sound

- Cellular Video
 - 1.3 Megapixel Rotating Camera with Video
 - Mobile Email
 - Instant Messaging (IM)
 - MEdia™ Net

See User Manual for Spanish Instructions
Additional charges may apply. Visit www.cingular.com for
more details. Phone features subject to change
without prior notice. All phone screens are simulated.
© 2007 AT&T Knowledge Ventures. All rights reserved. Subsidiaries and
affiliates of AT&T Inc. provide products and services under the AT&T brand.



Getting to Know Your Phone



Visit www.cingular.com/device-support for more information.

AT&T Music

AT&T Music provides the ultimate music experience with the push of the music button. Listen to your favorite music, watch the latest music videos, and stay in the know with music news and more.

- (Transfer and listen to your music with the integrated Music Player
- (Stream dozens of commercial-free music stations with Radio
- (Watch the latest music videos by clicking on Music Videos
- Personalize with ringtones and Answer Tones[™] under **Shop Tones**
- 💔 Instantly ID the title and artist of a song with MusicID
- (Get the latest music news, charts, and concert info from The Buzz



Transferring Music

Listen to music on your phone. Transfer your favorite tunes today!

- You must convert your music to either .MP3, .AAC, or .AAC+ format using the media player of your choice.
- Remove the battery and insert the microSD[™] card* (gold contacts facing down) into the slot at the top of the phone.
- Power on the phone and connect it to your PC using a USB data cable.*
- 4. When the Hardware Wizard pops up, click Cancel.
- The PC recognizes the phone as a Removable Disk under My Computer. Open the folder where your music is stored and transfer your files by dragging and dropping them onto the Removable Disk icon.
- When finished, press the Right Soft Key on the phone for Exit and disconnect the USB cable.



Note: The number of files you can store depends on the size and format options of the memory card.

Playing Music

To listen to music that you have transferred to your phone, follow these quick easy steps:

Playing Music with the Flip Open

- 1. Press the Key, select Music Player (1), then All Songs (1) or Playlists (2). Select a song or playlist.
- Press to play/pause. Press up or down on the Navigation Key to change the volume, and left or right to qo to the previous or next song.
- Press the Left Soft Key for Minimize to access other phone functionality while music is playing.

Playing Music with the Flip Closed

- Press and hold the ►/I Key. Select All Songs or a playlist. Use the left side volume keys to scroll.
- 2. Press ▶/II to play/pause the music. Use the ◀◀ or ▶▶ keys to go to the previous or next song.
- 3. Press and **hold** the ►/|| **Key** to exit the music player.





Cellular Video

Cellular Video brings your phone to life. Watch news, sports, weather, and entertainment clips on the go.

- 1. From standby mode, press the Left Soft Key for Menu.
- 2. Select CV (6), then press 😂 to connect.
- Once connected, select the program or category you wish to view and press

Personalize your CV Home Page

- 1. From the CV home page, select **EDIT** and press **S**.
- 2. Select the content you would like added or deleted from your CV home page and press .




Note: You can add up to 20 favorites. Parental controls available. See box insert for details. Access to Cellular Video requires a MEdia™ Max plan.



Taking Pictures

Capture everything around you in vivid detail via the 1.3 megapixel camera with video. Then share it instantly with friends via multimedia messaging.

- 1. To take a picture, press the **Key**.
- 2. Rotate the camera lens toward your subject. Press the volume keys to flip the viewfinder image.
- 3. Press **left** or **right** on the Navigation Key to adjust brightness and up or down for zoom.* Press the timer, or other options.
- 4. Press \bigsim to take the picture.
- 5. To send your picture, press the **Left Soft Key**. Add text, the address book, press 😂. Press the Left Soft Key to send.



Scroll down with the volume keys to **Take Photo** and press ▶/**II**. Images and videos are saved under My Stuff (7).

^{*}Camera resolution of 1280 x 960 does not support zoom function.

Mobile Email

Take your email with you. With mobile email, you can check your Yahoo!® Mail, AOL,® and MSN® Hotmail® quickly and easily from your wireless phone.

- 1. To download Mobile Email, press 🈂 to launch MEdia Net.
- Scroll and select Mail & Messaging (3), then Mobile Email, and press for Buy Now to download the application.
- 3. Select Yes when asked if you'd like to download Mobile Email.
- 4. Once downloaded, select Applications (2) to save Mobile Email.

To Launch Mobile Fmail

- From standby mode, press the Left Soft Key for Menu, select My Stuff (7), Applications (2), then Mobile Email.
- Select a provider and press . Enter your Screen Name/ID or Email and Password. Check the box to automatically connect in the future. Press the Right Soft Key to Sign In/On.
- 3. Scroll to an email and press
 to download its content.
- 4. Press et to delete or the **Right Soft Key** to reply or forward.



Text Messaging

When you need to communicate privately and quickly, use text messaging. You can text message to other mobile phones and email addresses.

- 1. From standby mode, press the Left Soft Key for Menu.
- 2. Select Messaging (2), then Create New Message (1).
- 3. Type your message.
- 4. When completed, press Send To.
- 5. Enter the recipient's telephone number or press for **Contacts** to select an existing contact.
- 6. Press the Left Soft Key to send.



Instant Messaging

If you subscribe to an instant messaging (IM) service such as AOL, MSN, or Yahoo! you can take the convenience and fun of IM on the go with your mobile phone.

- 1. From standby mode, press right on the Navigation Key to access IM
- 2. Highlight the IM community you want to enter, select Sign In/On, and press
- 3. The first time you enter a community, enter your Screen Name/ID or Email and your Password. Check the Auto Sign On/In box to be automatically connected in the future. Press the Left Soft Key to Sign In/On.
- 4. Select a contact that is currently online and press

 .



5. Enter your message and press \lefter twice to send. To end a chat, select Option, then End Conversation.



Note: When you receive an incoming instant message, a "new message" icon similar to this one will appear on the screen.

With MEdia Net, you can get the information that is important to you at a glance. Your local weather, your teams' scores, your movie theaters are all just a few clicks away.

- 1. Press 😂 to launch MEdia Net.
- 2. Scroll and highlight the content you want to view and press



Personalize your MEdia Net Home Page

- 1. From the MEdia Net home page, select **EDIT** next to My Links to add a link to your home page, and press
- 2. Select the content you would like added or deleted from the MEdia Net home page and press



Downloadable Fun

Personalize your phone with downloadable games, graphics and ringtones. AT&T gives you access to the latest games and graphics right on your phone and access to the best new ringtones from today's hottest artists. Personalize your phone today.

- 1. From standby mode, press the **Left Soft Key** for **Menu**.
- 2. Select AT&T Mall (5) and press

 .
- 3. Select Shop Tones (1), Shop Games (2), or Shop Graphics (3) and press .
- 4. Choose a category and press

 .



Organize Me

Stay organized and on schedule with time saving tools including a calendar, alarm clock, and notepad. All of these great tools are just a few clicks away.

- 1. From standby mode, press the Left Soft Key for Menu.
- 2. Select My Stuff (7) and press
 .
- 3. Select **Tools (6)** and press **\equiv**.
- Select Alarm Clock (1), Calendar (2), Notepad (3), or one of the other handy tools.



Multitasking

Multitask simultaneously with voice and data — browse the web, make calls, play games, send and receive messages, and listen to music. All at once.

- If you're involved in one task and want to launch another, press the Task Key (lower left side of phone), then press the Left Soft Key for Menu, select the task you want to launch, and press
- 2. To switch among multiple open tasks, just press the **Task Key** to display the task icon bar on the bottom of the screen, press **left** or **right** on the Navigation Key to select another task icon, and press **.**
- If you get a call while in another task (except playing music), you can accept the call, then return to the task while you're talking.



Optional Accessories

Accessories for productivity, convenience, and fashion are available at cingular.com.





microSD Memory Card









Stereo Headset

Portable Stereo Speakers

Vehicle Power Charger



CU500QSG/AT&T MCDZ0003101 (1.2)